

P-2602H-DxA Series

ADSL2+ VoIP IAD

Quick Start Guide

Version 3.40
5/2006
Edition 1


The logo for ZyXEL, featuring the word "ZyXEL" in a bold, blue, sans-serif font. The "Zy" is in a smaller font size than "XEL", and the "y" has a distinctive shape with a curved bottom.

Overview

This Quick Start Guide is designed to help you set up the P-2602H-DxA series devices (“P-2602H-DxA”). The P-2602H-DxA series is an ADSL2+ router with a built in 4-port switch and VoIP integrated access device (IAD).

Note: The screens in this guide reflect the P-2602H-D1 model.

The following figure shows how your P-2602H-DxA (**A**) connects your network to the Internet and provides firewall protection. It also shows how your device can make VoIP calls and calls to regular phones.




1 Requirements

Make sure you have the following things before you set up your P-2602H-DxA.

- Internet access - account information provided by your ISP, such as user name, password, and so on.
- VoIP account - You need the account information provided by your VoIP service provider (the company that lets you make phone calls over the Internet). This information might include your URI, number, and so on.
- Internet Explorer 6.0 or later or Netscape Navigator 7.0 or later, with JavaScript enabled.

2 Hardware Connections



- 1 DSL:** Use the gray ADSL cable to connect the **DSL** (or **MODEM**) jack on a splitter to this port. If a splitter is not provided connect the telephone jack to this port.
- 2 ETHERNET 1-4:** Use Ethernet cables to connect computers to this port for initial configuration and/or Internet access.
- 3 PHONE 1-2:** Use a telephone cable (and any telephone adaptors provided with your P-2602H-DxA) to connect your telephones to these ports. If you only have one telephone, you should use port 1.
- 4 POWER:** Use the power adaptor provided with your P-2602H-DxA to connect an appropriate power source to this port.

Note: If you are using T-ISDN (UR-2), connect the green wire to a TAE connector before connecting it to a telephone wall jack or the telephone splitter's **TEL** (or **PHONE**) jack.

5 Push in the **POWER** button. Look at the lights on either side of the P-2602H-DxA.


- The **POWER** light blinks during start-up and is green once the P-2602H-DxA is ready.
- Each **ETHERNET** light turns on if the corresponding **ETHERNET** port is properly connected. The lights blink when the P-2602H-DxA is sending or receiving data through the corresponding **ETHERNET** port.
- The **DSL** light stays on if a physical connection with the ISP is established. The **INTERNET** light stays on when Internet access is available.
- The **PHONE** lights stay on when your SIP account is registered and they blink if the receiver is off the hook.

If the **PHONE 1** or **PHONE 2** light is on, go to Section 4 to see how to make calls through the Internet.

If the **INTERNET** light comes on but the **PHONE** lights are off, go to Section 3.2 and use the **VOIP SETUP** wizard.


If the **INTERNET** light is off but the **DSL** light is on, go to Section 3.1 and use the **INTERNET SETUP** wizard to configure your Internet access settings.

If the lights are different than described, go to **Troubleshooting**.



3 Initial Configuration

1 Open your browser, and go to <http://192.168.1.1>.



2 Enter the password **1234**. Then, click **Login**.



If your browser cannot find this screen, make sure your browser is configured correctly. See **Troubleshooting** in the User's Guide for details.

3 Follow the directions in this screen.



4 Click **Go to Wizard setup**. Then, click **Apply**.




3.1 Internet Setup

Note: You should have the information provided by your ISP.

1 Click **INTERNET SETUP**.

2 Wait while the P-2602H-DxA tries to detect your Internet connection. If the P-2602H-DxA cannot detect your Internet connection, follow the directions. Enter the information provided by your ISP. Keep the default settings if your ISP did not provide some information.


3 When your Internet connection is setup correctly, the **INTERNET** light should be green. When you are finished click **Return to Wizard Main Page**.



3.2 VoIP Setup


1 Click **VOICE OVER INTERNET SETUP**.

Note: You should have the information provided by your VoIP service provider.



2 Enter the information provided by your VoIP service provider. Keep the default settings if your VoIP service provider did not provide some information. If you have a SIP account like **1234567@VoIP-provider.com**, the **SIP Number** is **1234567**, and the **SIP Service Domain** is **VoIP-provider.com**.

3 When you are done, the **PHONE** light should be on. Close the wizard and the main screen opens.



4 Phone Calls

When a **PHONE** light turns on, your SIP account is registered successfully. Dial a numerical SIP number (like “12345” for example) on your phone’s keypad. Use your voice service provider’s dialing plan to make calls through the Internet to regular telephone numbers. See your User’s Guide for other calling options.

Troubleshooting

If you cannot access the Internet, follow these steps.

- 1 Check the device’s lights. If they are different than what is described in Section 2, turn off the device, make sure the connections are correct, and inspect your cables for damage. Turn the device on again.
- 2 Follow the steps in Section 3 again. Make sure you enter the correct information. For example, if your account has a user name and password, make sure you type it correctly. In addition, if you are not sure which encapsulation your ISP uses, contact your ISP.
- 3 If you are using a new Internet account, contact your ISP to make sure it is active.
- 4 If you still have problems, see **Troubleshooting** in the User’s Guide.

If you can access the Internet, but you cannot make calls through the Internet, follow these steps.

- 1 Check the **PHONE** lights. If neither of them is on, make sure that your telephone is connected to the corresponding **PHONE** port.
- 2 Make sure the **VOICE OVER INTERNET SETUP** wizard screens are properly configured (see Section 3.2).
- 3 You can also check the VoIP status in the **Status** screen. See the User’s Guide for more information about this screen.

Viewing Your Product’s Certifications

- 1 Go to www.zyxel.com.
- 2 Select your product from the drop-down list box on the ZyXEL home page to go to that product’s page.
- 3 Select the certification you wish to view from this page.